

Premium Twist Mop with Scrubber Pad Owner's Manual

For customer support between
10:00 AM – 4:00 PM EST, please call:
Toll free 1-888-318-8521

Manufactured by Butler Home Products, Inc.
Mr. Clean and the Mr. Clean Man design are used
under license from The Procter and Gamble Company,
Cincinnati, Ohio
© 2000 Butler Home Products, Inc. Holliston, MA 01746


Lifetime Limited Warranty (excluding replaceable mophead)

If, at anytime, this product fails due to defects in materials and/or workmanship during normal household use, Butler Home Products, Inc. will replace it with the same product, or an equivalent product at no charge.

To Remove Mophead Assembly

Step 1

Position mop so that the **Hanging Cap** is on the floor, and the mophead is up. Spread mophead material to expose **Metal Handle** and **C-pin**.



Step 2

Remove **C-pin** by pushing pointed end of pin with thumb of one hand and pulling curved side of pin with other.

Step 3

Lift the black **Mop Connector** from the **Metal Handle**. Loosen the mophead from the large grip by pulling downward. Slide the entire mophead assembly down over both **Grips** and **Hanging Cap**.

NEAT TIP

To avoid misplacing the **C-pin**, immediately snap it back into the handle for storage.

WASHING INSTRUCTIONS

Your entire mophead assembly (including **Black Mop Connector**) is machine washable on **GENTLE CYCLE ONLY**. To prevent tangling, place the mophead assembly in a lingerie bag. Dry naturally. Do not put in clothes dryer.

REFILL INFORMATION

Fits Mr. Clean Premium Twist Mop No. 4145, Butler Cotton Blend Super Mop® No. 1591 and Butler Cham-It Super Mop® No. 1595.

To Replace Mophead Assembly or Attach Refill



Step 1


Position mop so that the **Hanging Cap** is on the floor and remove **C-pin** (if stored in the handle).

Step 2

Slide the end of the handle with **Hanging Cap** through the center of the mophead and the strands (as shown). Pull the mophead assembly up over both grips.

Step 3

Place the black **Mophead Connector** into the top end of the handle (doing this will raise the large grip towards the top of the handle).



Step 4

Firmly push the black **C-pin** back into the handle until it snaps into place. (Use the hole that goes through both the **Handle** and **Mophead Connector**.)

Step 5

Pull the end of the mophead assembly that has the **Tie Wrap** firmly around the wide end of the large **Twist Assist Grip** until snug.

